


DFZ 465 Parts

Condensing Unit




Pos.	Description	Qty	V 2008	Z 2008
10	Front Cover	1	3002117	-
15	Support Bracket, Front Cover	1	2742084	-
19	Conterplate, Hinge	1	2746090	-
20	Frame, Compressor/Engine Assembly	1	2746001	-
30	Bottom Cover	1	2742161	-
40	Frame	1	2746150	-
50	Right Side Cover	1	3002119	-
60	Left Side Cover	1	3002120	-
64	Spacer	1	3DSZ021	-
70	Anti-vibration Dumplers	4	3AVB015	-
80	Spring	2	3001223	-
82	Ground Wire	1	3TRC001	-
87	Exhaust Pipe	1	3TSM001	-
90	Support Bracket, Spring	2	2746070	-
100	Assembly, Left Hinge	1	2746058	-
110	Assembly, Right Hinge	1	2746057	-
120	Condenser Left Closing Plate	1	2746174	-
130	Condenser Fan Noozle	1	2746089	-
140	Closing Plate, Condenser, Right	1	2746061	-
150	Belt Stretcher, Bracket	1	3746165	-
160	Support Bracket, Right Side Cover	1	2746173	-
165	Bracket	1	2746014	-
180	Hinge	3	3CER011	-
190	Conterplate, Hinge	3	2700558	-
200	Condenser Right Crossbeam	1	2746035	-
210	Condenser Left Crossbeam	1	2746036	-
220	Upper Locking Plate	1	2746167	-
230	Stand-by compressor Suction Assembly	1	2746034	-
240	Support Bracket, Left Side Cover	1	2746072	-
250	Lifting Bracket	1	2746063	-
260	Door Micro Switch	1	3MCT008	-
270	Activator, Micro Switch	1	3CHV003	-
280	Canal	1	2746082	-
290	Electrical Box	1	2QECDFZN0	-
300	Defrost Air pressure Switch	1	3PRS051	-
310	Liquid Receiver	1	3ACP098	-
320	Non-return Valve	1	3VLR017	-
330	Flexible Hose	1	3TBG049	-
340	Non-return Valve	1	3VLR020	-
350	Condenser	1	3CND264	-
360	3-Ways Valve	1	3VLD011	-
380	Cap	1	3TPO049	-
390	Vibrabsorber	1	3AVB051	-
400	Support, Compressor Hose	1	2746114	-
420	Compressor	1	3CMP934	-
440	Vibrabsorber	1	3AVB052	-

450	Support Bracket, Crankcase Pressure Regulation Valve	1	2746110	-
460	Crankcase Pressure regulation Valve	1	3VRP007	-
470	Liquid Receiver/Separator	1	3ACP121	-
480	Filter Drier	1	3FLT176	-
490	Support Bracket, Filter Drier	1	2746016	-
495	Bracket, Filter Drier	1	2746015	-
500	Liquid Sight Glass	1	3INU046	-
510	Pressure Switch, Low Pressure	1	3PRS044	-
520	Pressure Switch, High Pressure	1	3PRS040	-
530	Support Bracket, Expansion Tank	1	2742035	-
540	Expansion Tank	1	3002191	-
550	Cap, Expansion Tank	1	3TPP064	-
560	Sump Bracket	1	2746099	-
570	Inner Spacer	1	3001447	-
580	Oil Sump	1	3001261	-
585	Gasket, Exhaust Tailpipe	1	3GUR038	-
590	Exhaust	1	3MRM007	-
595	Exhaust Pipe	1	3TSM001	-
600	Diesel Engine	1	3MTD025	3MTD025
610	Bracket	1	2746168	-
615	Sleeve, Air Intake	1	3MNC014	-
620	Bracket, Air Filter	1	3001403	-
630	Obstruction Indicator	1	3INI002	-
640	Air Filter Cartridge	1	3FLT113	-
650	Air Filter Assembly	1	3FLT102	-
660	Accelerator Solenoid	1	3ELM001	-
670	Ball Joint	1	3SND001	-
680	Ball Joint	1	3SND002	-
690	Support Bracket, Accelerator	1	3746198	-
700	not present	0	np	-
710	Holed Bolt, Oil Discharge	1	3BLL002	-
720	Flexible hose, Oil Drain Circuit	1	3TCS026	-
730	Cap	1	3TPO041	-
740	Fuel Filter Cartridge	1	3FLT085	-
750	Fuel Filter Assembly	1	3FLT104	-
760	Bracket, Fuel Filter	1	2746120	-
770	Flexible hose, Fuel Circuit	1	3TBG037	-
780	Flexible hose	1	3TBG036	-
790	Belt	2	3CGT229	-
800	Centrifugal Clutch	1	3FRZ040	-
810	Idler Assembly	1	2PLG093	-
820	Shaft	1	3001253	-
830	Ball Bearing	1	3CUS005	-
840	Spacer	1	3001255	-
850	Safety Spring Ring	1	3SEG001	-
860	Ball Bearing	1	3CUS005	-
870	Pulley	1	3PLG093	-

880	Washer, Ball Bearing	1	3001257	-
890	Screw	1	3VTE225	-
900	Pulley	1	3PLG101	-
910	Belt	1	3CGT235	-
920	Belt	1	3CGT224	-
930	Pulley	1	3PLG120	-
940	Alternator	1	3ALT005	-
950	Spacer	1	3001338	-
960	Support Bracket, Alternator	1	2746159	-
970	Spacer	1	3001337	-
980	Tightener, Alternator Belt	1	2746162	-
990	Bush	1	3BSS003	-
1000	Pulley	1	3PLG106	-
1010	Tightener, Support	1	2746160	-
1020	Electric Motor, AC	1	3MTR051	-
1030	Centering Flange	1	3001256	-
1040	Mounting Flange	1	3001273	-
1050	Fan Blade	1	3VNT030	-
1060	Idler Assembly	1	2PLG092	-
1070	Shaft	1	3001253	-
1080	Ball Bearing	1	3CUS005	-
1090	Spacer	1	3001255	-
1100	Safety Spring Ring	1	3SEG001	-
1110	Ball Bearing	1	3CUS005	-
1120	Pulley	1	3PLG092	-
1130	Washer, Ball Bearing	1	3001257	-
1140	Screw	1	3VTE225	-
1150	Spacer	1	3001282	-
1160	Water Pump Tightener Bracket	1	2746056	-
1170	Ball Bearing	2	3CUS005	-
1180	Bush, Ball Bearing	1	3001275	-
1190	Belt	1	3CGT225	-
1200	Spacer	1	3001255	-
1210	Safety Spring Ring	1	3SEG001	-
1220	Pulley	1	3PLG099	-

DFZ 465 Parts


Evaporator



Pos.	Description	Qty	V 2008
10	Evaporator	1	3EVP325
20	Exchanger Bracket	2	2700522
30	Intake Support Bracket	2	2749035
40	Insulating Spacing Panel	1	1TIS032
50	Defrost End Thermostat	2	3TMT068
60	Temperature Sensor	1	3SNS086
70	Expansion Valve	1	3BUL058
80	Orifice	1	3ORF006
90	Support Bracket, Expansion Valve	1	2749024
100	Fan Blade	3	3VNT025
110	Mounting Flange	3	2700548
120	Grid	3	3GRI057
130	Centering Flange	3	2700549
140	Electric Motor, DC	3	3MTR049
150	Brushes, Electric Motor DC	1	3SPZ001

DFZ 465 Parts


Electric Box



Pos.	Description	Qty	V 2008	B 2010	B 2011
3	Aerotor	2	3ARE002	-	-
10	Electric Box, Case	1	3QUA050	-	-
20	Cab Command	1	3TST028	3TST039	-
30	Connecting Cable, Cab Command	1	3CAV035	-	-
35	Temperature Sensor	1	3SNS085	-	-
36	Temperature Sensor	1	3SNS086	-	-
40	Power Relays Board	1	3SCH136	-	-
60	CPU Board, 12V	1	3SCH135	3SCH152	-
67	Hour Meter	1	3CTA012	-	np
70	Emergency Manual Starting Board	1	np	-	3SCH220
75	Buzzer	1	3SRN013	-	-
80	Remote ON/OFF Button	1	3PUL034	-	-
81	Protection, Remote Button	1	3CPF011	-	-
90	Thermal Overload Relay	1	3INT256	-	-
110	Auxiliary Contact	1	3CNT054	-	-
120	Contactor	1	3TLR282	-	-
130	Auxiliary Contact	1	3CNT053	-	-
140	Relay, Phases Sequence Control	1	3RSF007	-	-

DFZ 465 Parts


Diesel Engine



Pos.	Description	Qty	V 2008
10	Sump	1	3001263
20	Oil Filter	1	3RMD058
30	Oil Hose	1	3RMD141
40	Screw	1	3RMD142
50	Gasket Oil Hose	1	3RMD143
60	Oil Dipstick	1	3RMD084
70	Terminal	1	3RMD167
80	Oil Pressure Switch	1	3RMD044
90	Gasket Kit	1	3RMD185
100	Gasket, Cylinder Head	1	3RMD074
110	Cylinder Head	1	3RMD075
120	Gasket, Rocker Support	1	3RMD085
130	Rocker Support	1	3RMD144
140	Gasket, Rocker Cover	1	3RMD057
150	Rocker Cover	1	3RMD140
160	Gasket	1	3RMD052
170	Oil Cap	1	3RMD051
180	Seal Ring	1	3RMD087
190	Gasket	1	3RMD086
200	Glow Plug Hose	1	3RMD078
210	Glow Plug	3	3CDL004
220	Starter	1	3RMD026
230	Injection Hose	1	3RMD077
240	Injector	3	3RMD046
250	Hose, Injection Pump	1	3RMD076
260	Dumper	1	3RMD146
270	Nut	1	3RMD147
280	Screw	1	3RMD145
290	Terminal	1	3RMD167
300	Solenoid Valve, Start/Stop	1	3RMD023
310	Injection Pump	1	3RMD047
320	Thermostatic Valve	1	3RMD079
330	Gasket, Thermostatic Valve	1	3RMD080
340	Support, Thermostatic Valve	1	3RMD081
350	Gasket, Water Pump	1	3RMD083
360	Gasket, Water Pump	1	3RMD082
370	Water Pump	1	3RMD063
380	Water Thermostat	1	3RMD030
390	Terminal	1	3RMD167

DFZ 465 Parts

Road' Compressor




Pos.	Description	Qty	V 2008
10	Shut Off Valve	1	3RBN136
20	Gasket, Shut Off Valve	1	3RCC103
30	Filter, Suction	1	3RCC105
40	Gasket, Shut Off Valve	1	3RCC111
50	Valve Plate	1	3PSV003
60	Gasket	1	3RCC118
70	Cylinder Head	1	3RCC035
80	Screw, Cylinder Head Screw	11	3RCC104
90	Shut Off Valve	1	3RBN137
100	Gasket, Shut Off Valve	1	3RCC053
110	Oil pump	1	3RCC134
120	Ball Bearing	1	3RCC133
130	Safety Spring Ring	1	3RCC121
140	Plug, Oil Draining	1	3RCC139
150	Gasket	1	3RCC138
160	Filter, Oil Sump	1	3RCC137
170	Screw, Flange	1	3RCC129
180	Flange	1	3RCC130
190	Gasket, Shut Off Valve	1	3RCC111
200	Gasket, Kit	1	3KGC003
210	Plug	1	3RCC098
220	Plug	1	3RCC119
230	Screw, Oil Sump	1	3RCC136
240	Ball Bearing	1	3RCC133
250	Safety Spring Ring	1	3RCC121
260	Gasket, Front Casing	1	3RCC109
270	Front Casing	1	3RCC110
280	Shaft Seal	1	3PMS003
290	Kit Ring/Felt	1	3KIT116
300	Washer, Compressor Crankshaft	1	3RCC108
310	Spring Washer, Compressor CrankShaft	1	3RCC107
320	Screw, Compressor Crankshaft	1	3RCC106
330	Oil Sight glass	1	3RCC131
340	Gasket, Sight Glass	1	3RCC132


DFZ 465 Parts

Kit Completamento Fornitura ed Accessori Completion Kits and Accessories


Stand-by and Battery Connection Kit



Fuel Pump Kit



Other accessories



(+) The parts above may be optional for some model versions

Pos.	Description	Qty	V 2008
10	Electrical Connection Kit, Stand-by/Battery	1	1KCS005
20	Cap, Plug	1	3COP001
30	Cable	1	3CV2200
40	Socket, Mobile	1	3PSA018
50	Plug, Fix	1	3SPN027
60	Plug, Mobile	1	3SPN028
70	Fuse Holder	1	3BSF058
80	Fuse	1	3FSB032
90	Fuse Holder	1	3BSF056
100	Fuse	1	3FSB179
110	Fuel Pump, Kit	1	2KPG004
120	fuel Pump	1	3PMP013
130	Adapter, Elbow	1	3GMT021
140	Fitting	2	3RCR134
150	Clamp	4	3FSC055
160	Support Bracket, Fuel Pump	1	2746145
170	Dipping Pipe, Fuel Tank	1	3PCT002
180	Fuel Heater, Kit	1	3KIT375
200	Battery	1	3BTR003
210	Battery Box, Kit	1	1KIT035
220	Battery Box	1	2746140
230	Battery Box, Cover	1	2746144
240	Battery Box, Fixing Bracket	1	2746143
250	Battery, Positive Terminal	1	3MRS037
260	Battery, Negative Terminal	1	3MRS038
270	Hose, Water Draining	1	3TBG044
280	not present	1	np
290	Clamp	4	3FSC032